



# DK-5000 SERIES MANUAL

INSTRUCTION MANUAL

**DK-5005E /**

**DK-5010E / DK-5030E**

TYPE

**E**



Please note that misuse of this device may lead to injury to the user or damage to the device. Please observe all safety precautions and warnings in this Instruction Manual.

● Customer Service



**LINE SEIKI CO., LTD.**

Head Office 37-7 Chuo-cho, 2-Chome Meguro-ku,  
Tokyo JAPAN 152-0001  
Contact TEL : 03-3716-5151 FAX : 03-3710-4552  
E-mail webtrade@line.co.jp  
URL http://www.lineseiki.com


Thank you for purchasing our product, DK-5000 Type E.  
Please confirm that you have the correct device by checking the product label.  
Please read this Instruction Manual carefully before using this device to ensure correct usage.  
Please keep this Instruction Manual for future reference.

## ■ KEY OPERATION (Buzzer Setting and Preset Setting)

### Buzzer Setting

◆ Hold down [F] and press [SUB] to enter **Buzzer Setting Mode**. The display will show the "Buzzer Mode" options.

- 1.) Buzzer Mode is ON by default.
- 2.) When ON is selected, the buzzer will sound shortly when a count key is pressed while on **Count Mode**.



- ◆ Press [2] to toggle buzzer ON/OFF.
- ◆ Press [1] to toggle between **Buzzer Setting Mode** and **Preset Setting Mode** (see details below).
- ◆ Press [F] to leave **Buzzer Setting Mode** and return to **Count Mode**.

### Preset Setting

◆ When in **Preset Setting Mode**, the display will show the "Preset Mode" options.



◆ Press [2] to cycle between **Preset OFF**, **Preset ON with Continuous Count Mode**, and **Preset ON with Stop Count Mode**.

- 1.) When **Preset ON with Continuous Count Mode** is selected, the buzzer will sound for 1 second when the preset total count value, or multiples of it, is reached while on **Count Mode**. Count inputs are still accepted even after reaching the preset total count value.



- 2.) When **Preset ON with Stop Count Mode** is selected, the buzzer will sound for 1 second when the preset total count value is reached while on **Count Mode**. Counting is disabled after reaching the preset total count value. Counting is enabled again only after saving the Record, either by holding down [F] then pressing [5] or by holding down [#] (see Record Data w/o Reset and Record Data).



- ◆ Press [5] to increment the preset value. Holding down [5] will continuously increment the preset value. When [5] is held down long enough, the preset value may be incremented by tens, by hundreds, by thousands, or by ten thousands. (changeover in place value being incremented happens every 12 seconds)
- ◆ Hold down [SUB] and press [5] to decrement the preset value. Holding down [SUB] and also holding down [5] will continuously decrement the preset value. When [SUB] and [5] are held down long enough, the preset value may be decremented by tens, by hundreds, by thousands, or by ten thousands. (changeover in place value being decremented happens every 12 seconds)
- ◆ Press [F] to leave **Preset Setting Mode** and return to **Count Mode**.

F

+

SUB

## ■ Software Download



Dedicated Communication Software can be downloaded for free from our website  
<http://www.lineseiki.com/> (registration is required).

※ On the software, DK-5005E / DK-5010E / DK-5030E is recognized as DK-5005A / DK-5010A / DK-5030A respectively.